


WARMER DRAWER CONTROL/
CONTROL DE CAJON CALENTADOR/
CONTROLE TIROIR RECHAUD



TEMPERATURE PROBE
SONDA DE TEMPERATURA
SONDE THERMIQUE

COLORS CODE/CODIGOS/CODIFICATION DES COULEURS

R. - RED/ROJO/ROUGE
W. - WHITE/BLANCO/BLANC
Y. - YELLOW/AMARILLO/JAUNE
V. - VIOLET/VIOLETA/VIOLET
BR. - BROWN/CAFE/BRUN

WIRE ALAMBRE FIL	GAUGE MEDIDA CALIBRE	TEMP.°C	CSA	UL STYLE MODO UL STYLE UL
1	18	150	EXL-150	3321
2	20	150		10109
3	22	150		10109

CAUTION:DISCONNECT POWER BEFORE SERVICING UNIT.
AVISO:DESCONECTE LA ENERGIA ANTES DE REALIZAR EL MANTENIMIENTO
DEL ELECTRODOMESTICO.
AVERTISSEMENT:COUPER LE COURANT AVANT D'EFFECTUER LA REPARATION

318049904 REV.A