

COMPANION COFFEE MAKER
ACCESSORY 30"/76CM TRIM KIT




US CA NZ AU

Keep this document handy for easy reference.


- This Trim Kit is designed to complement your companion product if installing into 30" (760mm) wide cabinetry.
- For contact information or if you require service, assistance or replacement parts, see your 'Service & warranty' booklet.

This Trim Kit is designed to be installed **ONLY** with the FISHER & PAYKEL
- Companion Coffee Maker EB24DSX/EB60DSX
- or in combination with OB30/OB76 Ovens

1 CABINETRY SPECIFICATION



2 PARTS SUPPLIED




3 POSITION TRIM SURROUND ON CABINETRY

IMPORTANT!

- Ensure all packaging and protective film is removed from the Trim Surround before installing.

- ① Mark the center of your cavity at the front.
- ② Mount the Trim Surround with the small lip resting flat on the front edge of the cabinetry shelf.
- ③ Center the Trim Surround by lining up the small cut "V" in the lip with your center mark from Step 1.


Note: If installing Coffee Maker above an Oven, ensure both products are centered and aligned in the cabinetry.




4 SCREW THE TRIM SURROUND ONTO THE CABINETRY

Using the 4 supplied screws, secure the Trim Surround to the cabinetry in the correct hole positions, as shown.
Pre-drill as necessary to avoid splitting the wood.

IMPORTANT!
Do not screw through either center holes in the Trim Surround.




Secure the Trim Surround using the screw hole locations shown





5 SECURE THE TWO SUPPORT BRACKETS IN THE CAVITY

- ① Position left and right support brackets as shown inside, against the walls of the cavity. We recommend butting the brackets up against the rear frame of the Trim Surround.
- ② Secure through front and rear hole locations on both brackets using the screws supplied.




6 FIT THE FOUR RUBBER HOLE PLUGS

Fit the 4 supplied rubber plugs into the Trim Surround in the correct hole positions, as shown.



7 INSTALL YOUR COFFEE MAKER (REFER TO SEPARATE INSTRUCTIONS SUPPLIED WITH COFFEE MAKER)



- ① Install your Coffee Maker as per it's installation instructions. Ensure the slides are secured correctly
- ② Position your Coffee Maker in the cavity. Ensure the Coffee Maker and Trim Kit are correctly aligned and the Coffee Maker can open and close freely, before securing.